

installation instructions:

WOOD SHUTTERS

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

TOOL & MATERIAL CHECKLIST

- electric drill
- 1/8" drill bit
- proper screws for installation surface
- level
- pencil, marker, or chalk

IMPORTANT INFO

- Determine the position of the Shutter in relation to the Window.
- Be sure to purchase the correct screws for your installation surface.

INSTALL INSTRUCTIONS:

Decorative Hardware

1. Determine the position for the shutter by matching up the top and bottom of the shutter with the window and mark its position.
2. Mark the shutter where you will fasten it to your installation surface. (If installing larger shutters fasten on the right a left hand side in the center of the shutter.)
3. Using a 1/8" bit drill pilot holes where you marked the shutter.
4. Using a level set the shutter in place and fasten using the correct screws for your installation surface. Be sure no to over-tighten the screws.

